

PW-FKP65 - Prowler Front Kick Panel

Tools Needed For Installation

Drill with 1/4" Drill Bit
7/16 Open End Wrench
5/32 Allen Wrench

Wire Crimpers / Strippers

Installation Instructions:



Align the kick panel in the upper corner of the footwell and mark the 3 mounting holes



After marking the holes, drill them using a 1/4" drill bit



Once the holes are drilled, mount the kickpanel using the supplied hardware



Drill a hole through the pod for your speaker wire



After securing all the allen bolts and the 7/16 nuts run your speaker wire into the speaker pod



After attaching the speaker wires to the speaker install the speaker into the SSV Works kick panel. And press the grill over the speakerreplace



CORPORATE: SSV WORKS, 19528 VENTURA BLVD. #158 TARZANA, CA 91356
WEB: www.SSVworks.com FAX: 866-293-6751