

PW-RKP65 - Prowler Rear Kick Panel

Tools Needed For Installation

Drill with 1/4" Drill Bit
5/16 socket wrench
7/16 open end wrench
Wire Crimpers / Strippers

Installation Instructions:

**SSV
WORKS**



Place the pod in the front corner of the bed, using the screws provided screw the pod into 3 locations in the plastic bed



From the area behind the front seats, drill 2 holes through the bed and the pod using one hole as a guide, this will be for the allen bolt / nut, the second hole will be for your speaker wire



Using the 5/16 allen wrench and the 7/16 open end wrench tighten the bolt facing towards the front of the bed



After securing all the bolts run your speaker wire into the speaker pod



After attaching the speaker wires to the speaker install the speaker into the SSV Works kick panel.

**SSV
WORKS**

