

# RG-FKP69 - Front Kick Panel

## Tools Needed For Installation

Drill with 1/4" Drill Bit  
7/16 Open End Wrench  
5/32 Torx Wrench  
Wire Crimpers / Strippers

## Installation Instructions:



Remove the existing factory kick panel, Retain hardware for new kick panel



Using the 1/4" drill bit drill a hole in the top of the pod, this will be used to run the speaker wire out of the pod



**NOTE:** On the driver side it may be necessary to grind the top back edge, due to factory variances this may hit the metal bracket under the dash (see picture for grinding recommendation)

Install the new kick panel using the hardware from the factory kick panel,



Using the hole in the new kick panel as a guide drill a hole through the plastic footwell

After securing the allen bolt with the 7/16 nut run your speaker wire



After attaching the speaker wires to the speaker install the speaker into the SSV Works kick panel

