

# TX-RKP65 - Teryx Rear Kick Panel

## Tools Needed For Installation

Drill with 1/4" Drill Bit  
10mm socket wrench  
Wire Crimpers / Strippers

## Installation Instructions:



Remove the factory tie downs using the 10mm socket, you will re-use the hardware to install the speaker pod



Using the factory hardware and the 10mm socket install the speaker pod in the corner of the bed



Drill a hole through the pod and the metal inner bed for your speaker wire, use caution and be sure not to drill through the plastic bedside



After securing all the bolts run your speaker wire into the speaker pod



After attaching the speaker wires to the speaker install the speaker into the SSV Works kick panel.



Install the Grill over the speaker

**SSV**  
**WORKS**

CORPORATE: SSV WORKS, 19528 VENTURA BLVD. #158 TARZANA, CA 91356  
WEB: [www.SSVworks.com](http://www.SSVworks.com) FAX: 866-293-6751